




7




8
















9



10












①



②




③




①


② ADM code






~~x~~ = ~~x~~ → ②





✓ = ✓ → ④










4



5








**BURG
WÄCHTER**

Quick start

secuENTRY

ENTRY 7711 Keypad PIN

secu **ENTRY**



Hauptanleitung:
Main manual:
Manuel Principal :
Hoofdgebruiksaanwijzing:



www.burg.biz

BURG-WÄCHTER KG
Altenhofer Weg 15
58300 Wetter, Germany

BD Quick Start ENTRY 7711 PIN HBG/SWI 110322